

Floor Patch

RENEWAL COMPOSITE



Repairs holes and cracks in concrete floors, walls, and other surfaces with a tough, durable filler.

- Repairs holes and cracks
- For use on concrete, brick and metal
- Tough, durable filler finish
- Bonds securely to new or old concrete
- Compression strength is over two times as high as concrete
- Easy to mix and apply
- Good for interior/exterior uses
- Does not shrink

General Information

It adheres to concrete, bricks, masonry, and metal surfaces. Floor Patch bonds securely to new concrete or old concrete and the compression strength is over two times as high as concrete. Floor Patch is easy to mix and apply and will withstand light traffic after 5 hours and heavy traffic after 8 hours. Floor Patch is good for interior and exterior applications and has excellent resistance to water, oil, and most chemicals. Floor Patch is approved by the USDA for use in federally inspected meat and poultry plants.

Material Safety Data Sheets are available upon request.

Typical applications where Floor Patch can be used:

- Concrete floors and walls
- Metal Surfaces
- Bricks and masonry
- Loading Docks
- Heavy traffic areas
- Piers

Floor Patch is available in this size:

40 lbs. Kit (18 kg.)

Part No. 60943

DIRECTIONS

SURFACE PREPARATION: Remove grime and loose particles with a wire brush. If the surface concrete is weak or deteriorated, remove it until the good concrete is exposed. Roughen the surface for maximum adhesion.

MIXING: Mix all the base with all of the activator and stir for 3 minutes. Next, add this mix to the dry, salt free sand in the pail and mix with a trowel, spatula, or power tool of suitable size.

APPLYING: Spread Floor Patch with a trowel. Wetting the trowel lightly with water makes the application easier.

CURING: At 75°F (24°C), a 1/4" (6 mm) layer of Floor Patch will withstand light traffic after 5 hours and heavy traffic after 8 hours. Floor Patch will fully cure in 16 hours at room temperature. Full cure times are as follows:

TEMPERATURE	GEL TIME WITHOUT SAND	WORKING TIME WITH SAND	FULL CURE TIME
60°F (16°C)	30 MINUTES	80 MINUTES	32 HOURS
75°F (24°C)	15 MINUTES	40 MINUTES	16 HOURS
90°F (32°C)	8 MINUTES	22 MINUTES	8 HOURS

Floor Patch will not cure properly below 60°F (16°C)



LPS Laboratories • An Illinois Tool Works Company
P.O. Box 105052 • 4647 Hugh Howell Road • Tucker, GA 30085-5052 U.S.A.
TEL: (800) 241-8334 or (770) 934-7800 • FAX: (800) 543-1563 or (770) 493-9206
Internet Web Site: www.lpslabs.com

LPS® is a registered trademark of LPS Laboratories • ©2001 LPS Laboratories • All Rights Reserved • Rev. 09/2001 • Form #X60941

**CERTIFIED
ISO 9001**
QUALITY MANAGEMENT SYSTEM